













11. After the vehicle completely passed the weighing pads, the indicator will give a total weight and print if automatically printing function is selected. Then you can start next vehicle weighing.

**ansutek**  
Ph 0800 27 26 26

info@ansutek.co.nz  
www.ansutek.co.nz  
www.ansutekbiz.co.nz